



## Tango with handbrake

The handbrake for the Tango castor has been designed in response to users of mobility aid devices and other equipment who need to be able to brake and lock the castors by hand. Castor braking can be controlled manually using the brake handle. If the brake handle has a separate parking brake, this can be used to lock the castor and prevent it from rolling.

The castor is fitted into a horizontal tube and includes a tube adapter which is fitted and locked in the tube. The tube adapter can be designed according to customer wishes. The elegant castor fitting solution is quick and easy to mount.

The castor has been tested and approved in accordance with standard ISO 11199 for mobility aid devices.

The hand brake feature is available for 125 mm Tango castors with brake and directional lock. The feature can also be combined with the Tango castor incorporating a two-stage brake: total-stop brake and directional lock in the same castor.

## Technical information

Wheel diameter	125 mm
Fork material	Glass-fibre reinforced polyamide
Wheel material	Polypropylene centre and thermoplastic rubber tyre
Bearing of the wheel	Ball bearing
Tread hardness	Thermoplastic rubber tyre: 80 Shore A
Height	Around 160 mm, depending on mounting tube
<b>Standard colours</b>	
Fork and thread guards	Grey RAL 7042 Light grey RAL 7035 Black
Fitting options	Fitting into a horizontal tube. The tube adapter can be modified to accommodate customers' own tube frame design



Oy Mannerin Konepaja Ab, P.O.Box 3, 10901 Hanko, Finland  
Tel. +358 19 222 001, Fax +358 19 248 2000  
E-mail: [manner@manner.fi](mailto:manner@manner.fi), Internet: [www.manner.fi](http://www.manner.fi)

